

- | | |
|-----------------------------|-----------------------|
| 1 - TACHOMETER | 21 - OIL GAUGE |
| 2 - WATER TEMP | 22 - OIL GAUGE |
| 3 - OIL PRESSURE | 23 - OIL GAUGE |
| 4 - IGNITION | 24 - WATER TEMP GAUGE |
| 5 - START SWITCH YELLOW/RED | 25 - WATER TEMP GAUGE |
| 6 - 12 VOLT SUPPLY | 26 - WATER TEMP GAUGE |
| 7 - GROUND | 27 - FUEL GAUGE |
| 8 - 12 VOLT | 28 - FUEL GAUGE |
| 9 - START KEY SWITCH | 29 - FUEL GAUGE |
| 10 - 12 VOLT KEY SWITCH | 30 - BLOWER |
| 11 - IGNITION KEY SWITCH | 31 - BLOWER |
| 12 - BLOWER SWITCH | 32 - BILGE PUMP |
| 13 - BLOWER SWITCH | 33 - BILGE PUMP |
| 14 - BILGE PUMP SWITCH | 34 - FUEL SENDER |
| 15 - BILGE PUMP SWITCH | 35 - FUEL SENDER |
| 16 - TACH GAUGE | |
| 17 - TACH GAUGE | |
| 18 - TACH GAUGE | |
| 19 - VOLT GAUGE | |
| 20 - VOLT GAUGE | |

Note: Items 1 thru 7 connect to the engine terminal block.

