

Hatch Accelerator Kit Wiring Instructions Part #620-3316

Single Actuator Use

1. Red 14 gauge wire to 12V+ (Battery or Solenoid)
2. Black 14 gauge wire to Ground
3. White 14 gauge wires to linear actuator
4. Terminal strip to SPDT switch outer terminals
5. Center terminal on switch to ground

(Mom) ON-OFF-ON (Mom) SPDT Switch

Terminal Strip on Black Box

