

## Hatch Accelerator Kit Wiring Instructions Part #620-434

### Dual Actuator Use

1. Red 14 gauge wire to 12V+ (Battery or Solenoid)
2. Black 14 gauge wire to Ground
3. White 14 gauge wires to first linear actuator
4. Yellow 14 gauge wires to second linear actuator
5. BLACK screws on terminal strip to DPDT switch outer terminals (To operate the linear actuator connected to the YELLOW leads)
6. SILVER screws on terminal strip to DPDT switch outer terminals. (To operate the linear actuator connected to the WHITE leads.)
7. Center terminal on switch to ground

